

Vaisala Ultrasonic Wind Sensor WMT700

	WMT 7 0													
1	Measurement range	1												
	40 m/s WMT701	1												
	40 m/s + Accredited Wind Calibration (WMT701)	Α												
2	Temperature range													
	-10+60 C		A											
	-40+60 C -55+70 C		B C											
3	Heating													
	Non-heated version			1										
	Heated transducers			2										
	Heated transducers and arms			3										
	Heated transducers, arms and body			4										
4	Digital communication interface				^									
	RS-485 isolated RS-422 isolated				A B									
	RS-232 isolated				C									
	SDI-12 isolated				D									
5	Digital communication profile													
	WMT70 - poll mode (default)	9600b, 8, N, 1 Pol				0								
	WS425 - ASCII	2400b, 8, N, 1 Pol				1								
	WS425 - NMEA Extended (v 0183) WS425 - SDI-12 (v 1.3)	9600b, 8, N, 1 Aut 1200b, 7, E, 1 Pol				2 3								
	WS425 - ASOS (V 1.3)	2400b, 8, N, 1 Pol				4								
	ROSA - MES12	9600b, 8, N, 1 Pol				5								
	AWS520 - NMEA Extended (v 0183)	4800b, 8, N, 1 Aut				8]							
6	Digital communication units													
	m/s						A							
	knots mph						B C							
	km/h						D							
7	Analog output signals for wind speed channel							ı						
	Disabled							0						
	Voltage output	100 mV/m/s						1						
	Current output	420 mA	(0Range	e m/s)				3						
	Current output	0.2 mA/m/s 10 Hz/m/s						4 6						
	Push-Pull frequency output WS425 - voltage output	8 mV/mph						7						
	WS425 - frequency output (Push-Pull)	5 Hz/mph						8						
	Pull up frequency output (PNP)	10 Hz/m/s						A						
	Pull down frequency output (NPN)	10 Hz/m/s						В						
8	Analog output signals for wind direction channel								0					
	Disabled Voltage output	20 mV/Deg							0 A					
	Current output	50 uA/Deg							D					
	Current output 420 mA	44.444 uA/Deg							Ē					
	Potentiometer output (WS425)	0Vref (Vref = ex	ternal refere	ence voltage	from syste	m)			F					
9	Cable													
	None									1 2				
	Cable 2 m, cable connector, open leads on one e Cable 10 m, cable connector, open leads on one									3				
	MAWS cable 10 m	ena								4				
	AWS520 cable 10 m, shield connected to PE pin									5				
	Adapter cable for WS425 serial									6				
	Adapter cable for WS425 analog frequency output									7				
	RS485 Cable 2 m, cable connector, open leads o									8				
	RS485 Cable 10 m, cable connector, open leads	on one end								9 A				
	Adapter cable for WS425 analog voltage output AWS520 cable 10 m, shield not connected to PE pin									В				
		ROSA analog cable 10 m, cable connector, open leads on one end Junction Box with Cable 2meters								C				
	Junction Box with Cable 2meters									D				
	Cable 15 m, cable connector, open leads on one									E				
- 10	Cable 26 m, cable connector, open leads on one	end								F	J			
10	Mounting adapter Adapter 228869 only				Standard a	danter no	fiv				Α			
	Adapter 228869 only Adapter 228869 with WMT70FiX70 (suitable also for inverted mounting) Standard adapter, no fix Standard adapter with gene					pose fix			В					
	Adapter 228869 with WMT700FIX60-POM		·ai				plastic fix fo		ole		Č			
	Adapter 228869 with WMT700FIX60-RST				Standard a	dapter with	stainless st	eel fix for 6			D			
	Adapter 228777 only (used for old WS425 FIX30	/60)			WS425 co	mpatible ad	apter, no fix				E]		
11	Power - Reserved for furture purposes											1		
12	None Accessories											7	J	
12	None												Α	
	Bird cage												В]
13	Manual													_
	None English													1 2
	Japanese													3
	Chinese													4
	Russian													5

For freezing conditions select appropriate combination of heating and temperature ranges.

Accessori	es		
	Tool	Verifier	WMT70Verifier
		Cable Tightener Tool	237888SP
	Bird	Bird cage	WMT70BirdKit
		Bird perch	WS425BirdPerch
	Cable	Cable connector	WMT70Conn
		Cable 2 m, cable connector, open leads on one end	227567SP
		Cable 10 m, cable connector, open leads on one end	227568SP
		Cable 15 m, cable connector, open leads on one end	237890SP
		Cable 26 m, cable connector, open leads on one end	237889SP
		RS485 Cable 2 m, cable connector, open leads on one end	228259SP
		RS485 Cable 10 m, cable connector, open leads on one end	228260SP
		MAWS cable 10 m	227565SP
		AWS520 cable 10 m, shield connected to PE pin	229807SP
		AWS520 cable 10 m, shield not connected to PE pin	227566SP
		ROSA analog cable 10 m, cable connector, open leads on one end	231425SP
		Adapter cable for WS425 serial	227569SP
		Adapter cable for WS425 analog frequency output	227570SP
		Adapter cable for WS425 analog voltage output	227571SP
		Junction Box with Cable 2meters	ASM210719SP
	Mounting	WMT700 Mounting Accessories:	
	J	Adapter for FIX70	228869
		Fix70 (suitable also for inverted mounting)	WMT70FixSP
		Mounting adapter 60mm POM	WMT700FIX60-POM
		Mounting adapter 60mm RST	WMT700FIX60-RST
		Cross-arm (40x40x850mm)	WMT70CROSSARM
		WS425 Mounting Accessories:	
		Adapter for old WS425 FIX30/60	228777
		FIX30	WS425Fix30
		FIX60	WS425Fix60
		Sensor support arm for 60mm pole (655mm with integrated fix for item 228777)	WAC425