VAISALA

Vaisala Ultrasonic Wind Sensor **WMT700**

	14/1/7 7 6			1 1			r			r			
1	WMT 7 0 Measurement range			┟──┤			<u> </u>			┝───┟			
1	75 m/s WMT703	3											
	75 m/s + Accredited Wind Calibration (WMT703												
2	Temperature range												
	-10+60 C	Δ											
	-40+60 C	E											
2	-55+70 C	C											
3	Heating Non-heated version		1										
	Heated transducers		2										
	Heated transducers and arms		3										
	Heated transducers, arms and body		4										
4	Digital communication interface												
	RS-485 isolated			A									
	RS-422 isolated RS-232 isolated			B C									
	SDI-12 isolated			D									
5	Digital communication profile			_									
	WMT70 - poll mode (default)	9600b, 8, N, 1 Polled			0								
	WS425 - ASCII	2400b, 8, N, 1 Polled			1								
	WS425 - NMEA Extended (v 0183)	9600b, 8, N, 1 Auto send	i 1/s		2								
	WS425 - SDI-12 (v 1.3)	1200b, 7, E, 1 Polled			3								
	WS425 - ASOS ROSA - MES12	2400b, 8, N, 1 Polled 9600b, 8, N, 1 Polled			4 5								
	AWS520 - NMEA Extended (v 0183)	4800b, 8, N, 1 Auto send	i 1/s		8								
6	Digital communication units		-			•							
	m/s					А							
	knots					В							
	mph					С							
7	km/h Analog output signals for wind speed channel					D	J						
'	Disabled						0						
	Voltage output	100 mV/m/s					1						
	Current output	420 mA (0R	ange m/s)				3						
	Current output	0.2 mA/m/s					4						
	Push-Pull frequency output	10 Hz/m/s					6						
	WS425 - voltage output	8 mV/mph					7						
	WS425 - frequency output (Push-Pull) Pull up frequency output (PNP)	5 Hz/mph 10 Hz/m/s					8 A						
	Pull down frequency output (NPN)	10 Hz/m/s					В						
8	Analog output signals for wind direction channel												
	Disabled							0					
	Voltage output	20 mV/Deg						A					
	Current output Current output 420 mA	50 uA/Deg 44.444 uA/Deg						D E					
	Potentiometer output (WS425)	0Vref (Vref = external r	reference voltage	e from systen	ו)			F					
9	Cable		ererence renagi		.,								
	None								1				
	Cable 2 m, cable connector, open leads on one								2				
	Cable 10 m, cable connector, open leads on one	end							3 4				
	MAWS cable 10 m AWS520 cable 10 m, shield connected to PE pir	1							4 5				
	Adapter cable for WS425 serial								6				
	Adapter cable for WS425 analog frequency outp	ut							7				
	RS485 Cable 2 m, cable connector, open leads								8				
	RS485 Cable 10 m, cable connector, open leads	s on one end							9				
	Adapter cable for WS425 analog voltage output AWS520 cable 10 m, shield not connected to PE	nin							A B				
	ROSA analog cable 10 m, shield not connected to Pa								C				
	Junction Box with Cable 2meters								D				
	Cable 15 m, cable connector, open leads on one								Е				
	Cable 26 m, cable connector, open leads on one	end							F				
10	Mounting adapter			Standard -	lanter ac	fiv.				^			
	Adapter 228869 only Adapter 228869 with WMT70FIX70 (suitable als	o for inverted mounting)		Standard ac Standard ac			rnose fiv			A B			
	Adapter 228869 with WMT700FIX60-POM	o for inverted modifulity)		Standard ad				ole		C			
	Adapter 228869 with WMT700FIX60-RST			Standard ad						D			
	Adapter 228777 only (used for old WS425 FIX3)/60)		WS425 con						E			
11	Power - Reserved for furture purposes										_		
12	None										1		
12	Accessories None											А	
	Bird cage											В	
13	Manual												•
	None												1
	English												2 3
	Japanese Chinese												3
	Russian												5

For freezing conditions select appropriate combination of heating and temperature ranges.

Accessories Tool

- Verifier Cable Tightener Tool Bird cage Bird perch Bird
- Cable Cable connector Cable 2 m, cable connector, open leads on one end

WMT70Verifier 237888SP

WMT70BirdKit WS425BirdPerch

WMT70Conn 227567SP

	Cable 2 m, cable connector, open leads on one end	22/00/01
	Cable 10 m, cable connector, open leads on one end	227568SP
	Cable 15 m, cable connector, open leads on one end	237890SP
	Cable 26 m, cable connector, open leads on one end	237889SP
	RS485 Cable 2 m, cable connector, open leads on one end	228259SP
	RS485 Cable 10 m, cable connector, open leads on one end	228260SP
	MAWS cable 10 m	227565SP
	AWS520 cable 10 m, shield connected to PE pin	229807SP
	AWS520 cable 10 m, shield not connected to PE pin	227566SP
	ROSA analog cable 10 m, cable connector, open leads on one end	231425SP
	Adapter cable for WS425 serial	227569SP
	Adapter cable for WS425 analog frequency output	227570SP
	Adapter cable for WS425 analog voltage output	227571SP
	Junction Box with Cable 2meters	ASM210719SP
Mounting	WMT700 Mounting Accessories:	
Wounting	Adapter for FIX70	228869
	Fix70 (suitable also for inverted mounting)	WMT70FixSP
	Mounting adapter 60mm POM	WMT700FIX60-POM
	Mounting adapter 60mm RST	WMT700FIX60-RST
	Cross-arm (40x40x850mm)	WMT70CROSSARM
	WS425 Mounting Accessories:	
	Adapter for old WS425 FIX30/60	228777
	FIX30	WS425Fix30
	FIX60	WS425Fix60
	Sensor support arm for 60mm pole (655mm with integrated fix for item 228777)	WAC425